

Installation, service and operating instruction

Cetetherm AquaCompact DHW heater



EN

This manual is published by Cetetherm.

Cetetherm can without further notice make changes and improvements to the content in this manual if it is necessary due to printing mistakes, wrong information or changes in the hardware or software. All these types of changes will be included in future release of the manual.

Contents

1	Product overview	5
1.1	Working pressure and temperature	6
1.2	Packing format.....	6
2	Options	6
2.1	2PSA primary kit – Thermostatic 2-way control valve featuring.....	6
2.2	2PE primary kit - Electrical 2-way control valve featuring	6
2.3	3PE primary kit - Three-way control valve including	7
3	Installation.....	8
3.1	Siting.....	8
3.2	Hydraulic connections	8
3.3	Basic version	8
3.4	Commissioning	9
4	Setting the DHW flow rate	9
5	Electrical connections.....	10
5.1	Basic model with or without option 2PSA.....	10
5.2	Option 2P and 3P	10
5.3	Electrical power ratings table	10
5.4	Current limiting fuses.....	10
6	Electrical installation of control box, option.....	11
6.1	Controller components	11
6.2	Electrical wiring diagram, option 2PE	12
6.3	Electrical wiring diagram, option 3PE.....	14
7	User instruction control panel Micro 4000	16
7.1	Display settings (HMI)	17
7.2	Setting Date and Hour	17
8.	End user Mode	18
8.1.	Changing the Simple DHW S1 setpoint.	18
8.2.	Safety function.....	18
9.	Technician access level	19
9.1.	Login.....	19
9.2.	Log out.....	20
9.3.	Main Menu.....	20
9.4.	S1 Sensor menu.....	20
9.4.1	Temperature Setpoint(s) and clock program(s)	20
9.4.2	High and Low S1 temperature alarm	22
9.4.3	S1 Temperature controller	23
9.5.	Thermal treatment function	24
9.6.	Safety function.....	25
9.7.	ECO function.....	26
9.8.	Pump(s) menu.....	27
9.9.	Test sequence.....	27
9.10.	Modbus RTU Communication Menu	28
9.11.	Wired Inputs / Outputs menu.....	30
10.	Configuration access level.....	31
10.1.	Login.....	31
10.2.	Logout.....	31


Cetetherm AquaCompact
Installation, service and operating instructions

10.3.	Configuration menu	32
11.	Alarms/Functions and acknowledgement.....	34
11.1.	Alarms	34
11.2	Functions	34
11.3	Events'list	34
12.	Production RESET	35
13.	Trouble shooting	36
14.	Maintenance and repairs	37
14.1	Antibacterial treatment of the Aquatank	37
14.2	Clean the heat exchanger plates (P series)	38
14.3	Clean the fusion-bonded or copper brazes plate heat exchangers (F/B-series)	38
14.4	Open the control box	39
14.5	Fuses replacement	39
14.6	Pumps' number	40
14.7	Relay 1, 2 and 3 wiring	40
14.8	Remote control contact	41
15	Assembly of the charging kit to the Aquatank	42
15.1	Specific points for assembling the M3 charging kit	45
15.2	Mounting the flexible hose onto the tank.....	46
16	Flowcharts.....	47
16.1	Flowchart AquaCompact	47
16.2	Flowchart AquaCompact with primary kit 2PSA.....	48
16.3	Flowchart AquaCompact with primary kit 2PE	48
16.4	Flowchart AquaCompact with primary kit 3PE	49
17	Wiring the charging pump.....	50
18	Special instructions for options	51
18.1	Special instructions for 2PSA primary kits	51
18.2	Special instructions for 2PE primary kit.....	51
19	Commissioning report.....	52
20	Declaration of Conformity	53
21	Warranty	54
	How to contact Cetetherm	54


1 Product overview

The basic version of the Cetetherm AquaCompact DHW heater, semi-instantaneous system includes:


AquaCompact 30 – basic format




AquaCompact 60 – basic format



AquaCompact M3 – basic format



Aquatank



1.	Storage tank, 316Ti stainless steel storage tank, with a heat-insulated cover	5.	Connector hose between tank and charging pump, thermally-insulated
2.	Plate heat exchanger, 316-grade stainless steel fusion-bonded, copper-welded or dismantable plates and gaskets	6.	Connector hose between exchanger outlet and upper tank, thermally-insulated (plates and gaskets exchangers only).
3.	Balancing valve	7.	Charging kit support
4.	Charging pump		

1.1 Working pressure and temperature

Version	Primary side		Secondary side	
	Max working pressure (bar)	Max temperature (°C)	Max working pressure (bar)	Max temperature (°C)
CB	10	100	10	85
M3	10	100	10	85
2PSA Kit (CB/FB/M3)	10	100	10	85
2PE kits (CB/FB/M3)	10	100	10	85
3EPkits (CB/FB/M3)	10	100	10	85

1.2 Packing format

AquaCompact is delivered in three packages:

- storage tank
- insulation
- exchanger kit.

2 Options

There are three different control systems available as option.

2.1 2PSA primary kit – Thermostatic 2-way control valve featuring

- One 2-port control valve, PN25
- One programmable Immersion temperature sensor
- Screw-in connection fixtures

The primary circuit is pre-assembled (valve body). Follow the assembly instructions end of this manual, assembly of the charging kit.

Bulb thermostat to be installed at the end of the the fitting. Slotted bulb end, to be positioned slot-end upwards

Copper capillary tub

Setting thermostat




2-port control valve

2.2 2PE primary kit - Electrical 2-way control valve featuring

- One 2-port PN25 valve body
- One NTC10k temperature sensor
- One actuator, 24V AC/ 0-10V DC signal or 230V 3 points with return to zero
- One Control box with piping and support


The primary circuit is pre-assembled on the exchanger. Follow the assembly instructions end of this manual, assembly of the charging kit..



2.3 3PE primary kit - Three-way control valve including

- One 3-port control valve, PN16
- One primary pump, PN10
- One actuator, 24V AC feed-in and 0-10V DC controller current
- One control box including PID controller and power PCB
- Primary piping, sized differently according to heat exchanger type
- Control box support

The primary circuit is pre-assembled on the exchanger. Follow the assembly instructions end of this manual, assembly of the charging kit.



3 Installation

3.1 Siting

The AquaCompact hot water heater shall be installed in a dry place where room temperature is below 40°C, and ideally in ventilated premises.
AquaCompact is placed preferably on a sub-base footing.

3.2 Hydraulic connections

Connect the charging kit (exchanger + control valve + charging pump) to the storage tank using the interlink kit.



Make arrangements for fitting the insulation onto the tank before connecting up the piping.

The AquaCompact module can run without a recirculation system fitted.

To avoid creating a galvanic coupling, check that the materials used in the installation have similar corrosion potentials.


3.3 Basic version

Assembly: refer to the instructions given end of this manual, assembly of the charging kit..
Connect the primary supply and return connections.
Connect the cold water supply, hot water outlet and the recirculation system to the tank.

Fit the tank with a safety valve, a drain valve in the top section and a draw-off in the bottom section.
NOTE: The valve is a compulsory fixture that has to be pre-loaded at the storage tank operating pressure.

NOTE: The safety valve on the charging kit only protects the secondary system – it will neither protect nor surge-feed the installation and the volume stored, in correspondence with local rules.

The safety valve shall have the same diameter as the cold water inlet fixture



Top section connection



Exchanger support + accessories
(size will vary with exchanger type)



Bottom section connection, shut-off valve inserted between the conduit hose and the cold water inlet fixture.

3.4 Commissioning


- Flood the various circuits and flush bleed the pumps.
- Power-up.
- Set the secondary (charging) flow rate using the setting valve (read-off + setting)

NOTE: When first heated, the water in the tank will expand, increasing the pressure. A water hammer-arrester-type surge tank qualified for DHW systems may be fitted to prevent the relief valve from opening. Check the water network pressure.

4 Setting the DHW flow rate

The secondary DHW flow rate is set with the tank full and the primary circuit at nominal operating temperature and at the available exchanger power capacity required for the generator.

1. Fully open the control valve on the primary side.
2. If a 3-way control valve is fitted, wait for it to open completely.
3. Adjust the secondary flow circuit, as set out in the table below.
The flow rate can be read by pressing on the red pushbutton and reading the index marker against the float.



P(kW) DHW T(°C)	30	40	50	60	70	80	90	100	125	150	175	200	240
10 > 55°C	9.5	13	16	19	22	25.5	28.5	32	40	48	56	63	76
10 > 60°C	8.5	11.5	14	17	20	23	26	28	35	43	50	57	68
5 > 70°C	6	9	11	13	15	17	20	22	27	33	38	44	53



The recirculation flow rate must be 60% maximum of the secondary flow rate.

5 Electrical connections

All devices shall be connected in compliance with the governing standards.



All work on control box and other electrical components must be done by qualified people.



The main electrical box should be equipped with short-circuits protection

5.1 Basic model with or without option 2PSA



The charging pump has to be powered constantly.

5.2 Option 2P and 3P

For more information about the Operator Control box, see chapter [6 Electrical installation of control box, option](#), and forward.



Power the control box via a single-phase 230 V + ground.
Electrical system components pre-cabled according to the hardware ordered.

5.3 Electrical power ratings table

VERSION	Primary pump type	Primary pump consumption. W, A	Secondary pump type	Secondary pump consumption, W, A	TOTAL ¹⁾
Basic / Basic+2PSA	-	-	UP20-45N	120 W 0.5 A	120 W 0.5 A ²⁾
Basic / Basic +2PSA	-	-	UPS 32-80N	220 W 1.0 A	220 W 1.0 A ²⁾
Basic + 2PE primary kit	-	-	UP20-45N	120 W 0.5 A	150 W 1.6 A
Basic + 2PE primary kit	-	-	UPS 32-80N	220 W 1.0 A	250 W 1.6 A
Basic + 3PE primary kit	Magna 1 32-80	151 W 1.22 A	UP20-45N	120 W 0.5 A	305 W 1.8 A
Basic + 3PE primary kit	Magna 1 32-80	151 W 1.22 A	UPS 32-80N	220 W 1.0 A	405 W 2.6 A
SINGLE-PHASE 230 VOLTS + GROUND					

¹⁾ Including control box and actuator (except 2PSA kits) electrical consumptions.
Figures are rounded up to the nearest higher value.

²⁾ Has no control box

5.4 Current limiting fuses

Power cards are equipped with fuses, labelled FU1 to FU5 on the printed circuit.

Fuse	FU1	FU2	FU3	FU4	FU5	FU6	FU7
Protection	PUMP 1	N/A	PUMP 3	N/A	PCB	24V AC	24V DC
Size (mm)	5x20	5x20	5x20	5x20	5x20	5x20	5x20
Rating	2.5A		2.5A		200mA	1 A	1 A
Voltage	250V	250V	250V	250V	250V	250V	250V

Safety fuses are supplied inside the control box.

6 Electrical installation of control box, option

Power supply the control box with 230VAC 50 Hz. The control box with the controller Micro 3000 is called the secondary control box.




Power supply the control box with 230V 50 Hz + Earth, using electric protection in the main electric power box. The TWS control box is a secondary electrical control box. Human protections and protections against short circuits and over intensity must be installed in the main electric box.



Earth (Ground) must be wired to the control box to avoid any risk of electrical shock when touching the unit. Neutral and Phase must be respected: do not invert.

6.1 Controller components




- | | | | |
|---|--|---|-------------------|
| 1 | Temperature Controller Micro 4000 | 4 | Power PCB ADE-430 |
| 2 | Main switch, bipolar. | 5 | HMI cable |
| 3 | Protected customer power supply (N, L, Earth) | 6 | HMI (rear view) |




Use a 3 poles power supply cable with yellow/green earth wire of the following types: H05-VVH2-F, H05-V2V2-F, H05-V2V2H2-F, H05-Z1Z1-F, H05-Z1Z1H2-F, H05-RR-F, H05-VV-F. Wire section: 2,5mm².

Do not tin the cable ends which will be exposed to contact pressure in the terminal blocks.




Strip the cables as shown opposite. Be careful not to damage the insulation of the various electrical wires.

6.2 Electrical wiring diagram, option 2PE



Remote contact: Volt free contact between M and D5 terminals on the temperature controller PCB.
 Open Contact (by default) = unit operating normally, **Closed contact**= unit in standby = no temperature regulation




Component	Bornes Terminal
Servomotor	34+32
Actuator	34+33
Servomotor	34


Component	Bornes Terminal
Servomotor	N
Actuator	L
Servomotor	e
Neutral	l
Phase	a
	+ -

NOTE: If 230V 3pts actuator wiring, see [18 Special instructions for options](#).

6.3 Electrical wiring diagram, option 3PE




Remote contact: Volt free contact between M and D5 terminals on the temperature controller PCB.
 Open Contact (by default) = unit operating normally, **Closed contact= unit in standby = no temperature regulation**



7 User instruction control panel Micro 4000

When the unit is power supplied, wait one minute before navigating into the menu.



Rep	Designation
1	ⓘ key to display firmware/software versions. It is equipped of an orange LED if point in manual OR Green flashing if modbus connection with BMS writing priority. Please refer to specific chapters.
2	Alarm(s)/Function(s) 🔔 key, refer to specific chapters. Equipped with a LED. In case of pending alarm a red LED is flashing. In case of pending function (like thermal treatment, Eco...), led will green flash. In case of multiple functions, it will orange flash until last function has ended.
3	«Escape» key, to step backwards into the menu structure or to cancel pending parameter value.
4	⬆/+ key, to access to previous menu line OR to increase setting value.
5	⬇/- key, to access to next menu line OR to decrease setting value.
6	Enter (✓) key, to validate a parameter value or a choice (like On or Off)
7	Display (8 lines of 30 characters).
8	Keys' functions

Display :



For any modification of setpoint(s), parameter(s) or function(s), it is mandatory to save changes. Otherwise, the changes will be lost in the event of a power cut. Go to line 3, then press Enter (✓) key and select "Yes" then Enter to save data. **An automatic data saving is also performed every day at night (1h00).**

7.1 Display settings (HMI)

1. Press a few seconds on « Escape » key to access to HMI settings: Then press (✓) key	1 / 2 HMI settings Local connection
2. Press on ▼ key then on ✓ key to change backlight colour. There are 2 possible choices: White or Blue. Change colour by pressing ▼ and ▲ keys. Once done, press on ✓ to validate the choice. Press on ▼ key to access to next line.	HMI settings 2 / 6 Vxx.xx xxxx Backlight color Blue ...
3. Press on ✓ key to change backlight duration. Use ▼ and ▲ keys to change the value and press ✓ key to validate. 0 (default value) = permanent backlight 300 = Backlight stop after 300 seconds (5 mins) if no key pressed. <u>Note:</u> When backlight is off, pressing any key will activate it for the defined duration. Press ▼ key to access to next line	HMI settings 3 / 6 ... Backl.turn off ti. 0 ...
4. Process the same way to adjust contrast and brightness if needed.	HMI settings 4-5 / 6 ... Contrast 60 Brightness 60
5. The last line is not effective. Keep the value to « No ».	HMI settings 6 / 6 ... Firmware Update No
6. Press « Escape» key, then ▼ to point « Local Connection» line and press ✓ key to exit from HMI settings and get back to the main menu (home screen).	2 / 2 HMI settings Local connection

7.2 Setting Date and Hour

1. Go to Line #1. This can be done by pressing several times « Escape » key or by pushing ▲ key several times if needed.	STANDARD 1/t 11.10.2022 14 :06 :57 ...
2. Press on ✓ key and using ▲ and ▼ keys, change the current date. Then, press on ✓ key to change the month and process the same way to change the year if needed.	STANDARD 1/t 11.10.2022 14 :06 :57 ...
3. Setting hour. Process the same way as above to change hours, minutes and seconds still by using ▲ / ▼ keys and confirming by pressing ✓ each time.	STANDARD 1/t 11.10.2022 14 :06 :57 ...
When settings are done, line No.1 remains highlighted.	STANDARD 1/t 11.10.2022 14 :06 :57 ...
It is now possible to navigate into the menu by pressing ▲ / ▼ keys.	

8. End user Mode

Following changes can be done in end-user mode:

- Changing simple temperature setpoint
- Activate safety function

These changes (except date and hour) are indicated by the logo « ▶ » at the end of corresponding line.

8.1. Changing the Simple DHW S1 setpoint.

Please set a hot water production temperature in line with current national legislation and recommendations (UTD, Standards EN, ISO etc.)

All countries have different rules for how hot or cold tap water should be.

Cetetherm recommends the hot water temperature is at least 55°C and a hot water recirculation not less than 50°C.

At a temperature below 50°C there is a risk of bacterial growth. Note that at temperatures above 60°C the risk of scalding increases.

Set points above 63°C result in an increased risk of precipitation of lime scaling on the surfaces of the heat exchanger.

Default temperature setpoint is 60°C. To change it, refer to instructions below:

1. From the main menu, use ▲ / ▼ keys to go to line #6 as shown here: Then press on ✓ key.	STANDARD 6 / t ... S1 : Actual setpoint 58°C
2. S1 menu appears. Select line #2 using ▼ key. Then press twice on ✓ key.	S1 MENU 2 / 2 S1 setpoint 58°C ▶
3. Adjust setpoint value using ▲ / ▼ keys and confirm by pressing ✓ key. To cancel new setpoint value, just press « Esc » key.	58 °C 0°C ↓ 85°C [--- --- --- --- --- --- --- --- --- ---]
4. If no other change required, you can save the new setpoint at line No.3 (equal line 3 of main menu). Otherwise, press “Esc” twice to get back to main menu.	Save changes -----



If the green led of ⓘ key is flashing, it is not possible to change the setpoint. To solve this, access to technician level (see further on), go to “Communication” sub-menu and select « Modbus RTU », then press ✓ key. Go to the last line « Writing priority » and select « POL468 » then press ✓ key. The green LED will stop flashing. You can now change the setpoint. When done, do not forget to go back to Communication\Writing priority and to select “BMS”.

8.2. Safety function

This function power supplies the 4 pumps’ relays (even if there are no 4 pumps connected).

This energies the 4 pumps power supplies without checking if the pump is faulty or not.

Furthermore, pump(s) signals (for variable speed ones on P1/P2) and actuator signal are also forced to a preset value.

Valve signal is 50%, (5V) and Pump(s) signal is 100%, 10V.

Settings:

1. From the main menu and using ▲ / ▼ keys, go to corresponding line as shown: Then press ✓ key.	STANDARD l/t ... Safety function OFF ▶
2. To activate the safety function, press on ✓ key	Safety function 1/3 Enable OFF
3. Select « ON » using the ▼ key and press ✓ key.	✓ OFF ON

<p>4. Now, display has changed to « Enable ON » and the alarm key green flashes, indicating a function is on-going.</p>	<table border="1" style="width: 100%;"> <tr> <td>Safety function</td> <td style="text-align: right;">1/3</td> </tr> <tr> <td>Enable</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>Pump signal setpoint</td> <td style="text-align: right;">100%*</td> </tr> <tr> <td>Valve signal setpoint</td> <td style="text-align: right;">50%*</td> </tr> </table>	Safety function	1/3	Enable	ON	Pump signal setpoint	100%*	Valve signal setpoint	50%*
Safety function	1/3								
Enable	ON								
Pump signal setpoint	100%*								
Valve signal setpoint	50%*								
<p>5. To stop the function from line#1 of safety function menu, press twice on ✓ key (OFF state on display). The alarm/function button stops flashing (except if another alarm/function is on-going). Exit this sub-menu by pressing « Esc » key.</p>									

* : It is not possible at this access level to change pump and valve signal setpoint values

9. Technician access level


Technician access level allows to:

- Enable all sub-menu access (not possible from end-user access level)
- Adjust temperature setpoint(s) as per clock program(s)
- Enable/Disable functions like Eco, Booster, Thermal treatment...
- Check and/or force contact(s) or signal(s) output(s)
- Access to extended functions for specific applications, like primary tanks' charging pump(s) management or heat recovery for solar or geothermal applications
- Enable/Disable Modbus communication with priority or not to BMS writing.

9.1. Login

Access code is 1000.

1. From the main menu, go to line#2 : Password enter ▶. Then press ✓ key
OR
Press a few seconds on ✓ key
2. Display indicates « Login » and a cursor is placed on 0 - - -
3. Using ▲ / ▼ keys (meaning + / -), enter the 1st digit and validate by pressing ✓ key. The 1st digit must be 1. So you have to display 1 - - - by pressing once the + key, then pressing ✓ key.
4. Now comes the 2nd digit that must be 0 (zero). Just press on ✓ key as the default digit value is already zero.
5. Repeat the same operation for 3rd and 4th digits that must be zero also. For that, just press twice the ✓ key.
6. Once correct code is entered, information display appears (hardware/software versions, controller reference...). Press « Esc » key to come back to the main menu.
The display now shows one key on its top right corner, indicating technician access level is activated. Now, most of the lines show « ▶ » at their end, meaning their access is now possible:



Remark: After 10 minutes without pressing any key, the software logs out from technician level, the key disappears, and the software is back to end-user access level.

9.2. Log out

You don't have to wait 10 minutes until logging out. It is possible to log out at any time. For that :


1. Press a few seconds on ✓ key
2. Select « Log off » by pressing √ key
3. Press ✓ key
4. The key symbol has disappeared from the display. Access level is now back to end-user.
5. Save parameters, line No.3



Except for specific reason, DO NOT log off if points let in manual mode (with the ⓘ button orange flashing). Please refer to « Wired inputs-outputs » sub-menu.

9.3. Main Menu

To access to the first line, press several times « Esc » key OR ▲ key.

Display	Meaning
STANDARD l/t ↔	Standard mode (always). l=No of current line, t=total lines' number (variable, as per sensor(s)' number and activated extended function)
jj.mm.aaaa hh :mm :ss	Date and time
Password enter ▶	Log in / Log out
Save changes -----	 After changing parameters/activating functions, access this line, press Enter, select "Yes" and press Enter to save data
S1 : Second. Outlet T° 60°C	S1 (DHW) temperature sensor, read only
S1 : Actual setpoint 60°C ▶	Access to S1 sub-menu
Y1 : Primary valve nnn%	Primary control valve signal to the actuator, reading only
Thermal treatment OFF ▶	Access to thermal treatment sub-menu
Safety function OFF ▶	Access to safety function sub-menu
ECO / BOOSTER ARRETE ▶	Access to ECO/Booster function(s)' sub-menu
Pump(s) menu P1 P3 ▶	Access to pump(s) menu + configured pump(s)' number indication
Extended functions ▶	N/A for AquaCompact.
Test sequence ▶	Access to test sequence sub-menu
Communication ▶	Access to Modbus RTU communication sub-menu
Wired inputs – outputs ▶	Access to inputs / outputs reading / writing sub-menu

Please refer to next pages to get detail of each sub-menu.



All functions: Thermal treatment, Eco are disabled.
Each installation is different. Functions 'parameters have to be set according to the site and then can be enabled and adjusted if required.

9.4. S1 Sensor menu


This menu allows to:

- Adjust one or more daily or weekly temperature setpoint(s) as per clock program(s).
- Adjust high and low temperature alarm setpoints
- Adjust PID parameters

9.4.1 Temperature Setpoint(s) and clock program(s)



If the green led of ⓘ key is flashing, it is not possible to change the setpoint(s). To solve this, access to technician level (see further on), go to "Communication" sub-menu and select « Modbus RTU », then press ✓ key. Go to the last line « Writing priority » and select « POL468 » then press ✓ key. The green LED will stop flashing. You can now change the setpoint. When done, do not forget to go back to Communication\Writing priority and to select "BMS".

<p>1. From the main menu and using \blacktriangle / \blacktriangledown keys, go to line #6 as shown : Then press \checkmark key to access to S1 sub-menu</p>	<pre> STANDARD 6 / t \leftrightarrow ... S1 : Actual setpoint 60°C \blacktriangleright ... </pre>
<p>2. Go to line No.2 and press \checkmark key to access to setpoint(s) settings and clock program(s)</p>	<pre> S1 MENU 2/ 8 \leftrightarrow ... S1 setpoint 60°C \blacktriangleright ... </pre>
<p>There are 2 methods to adjust setpoints: a) Default setpoint if no clock program defined \rightarrow b) Different setpoints or not depending on weekday and hours of the day. It is possible to get up to 6 different setpoints per day and different from day to day.</p> <p>We describe here the 2nd method, the first one being described in the end-user access level (simple setpoint without clock program).</p> <p>① : Current day of the week is indicated by a cross (x) into the S1setpoint schedule menu.</p>	<pre> S1 setpoint schedule 1/11 \leftrightarrow Setpoint w/o Schedule 60°C Monday 60°C Tuesday x 60°C Wednesday 60°C Thursday 60°C Friday 60°C Saturday 60°C Sunday 60°C Copy Monday from Tue. To Sun Activate copy NO </pre>
<p>Clock program. Let's take the following sample:</p> <ul style="list-style-type: none"> • S1 setpoint 60°C from 6h00 to 22h00 Monday to Friday • S1 setpoint 55°C from 22h00 to 6h00 Monday to Friday • S1 setpoint 55°C the weekend, all day (Saturday+Sunday) <p>Access to line #2 and press \checkmark key.</p>	<pre> S1 setpoint schedule 2/11 \leftrightarrow S1 Sp without schedule 60°C Monday 60°C ... </pre>
<p style="text-align: center;"> Always start on Monday to duplicate time program to other week days</p>	
<p>Display looks like this: * : * means all the time=the whole day. If the same temperature setpoint is required during all day, let « * : * » and just indicate the setpoint temperature. ① : 0°C value means last current setpoint will be used. If all days get 0°C, the simple temperature setpoint will be used (60°C by default).</p>	<pre> d01 : Monday 1/12 \leftrightarrow Time 1 * : * Value 1 0°C ... Time 6 * : * Value 6 0°C </pre>
<p>Press on \checkmark key and use \blacktriangle / \blacktriangledown keys to display 0 (0 hour or midnight) then press \checkmark key to validate. Next, set minutes that can also be changed using \blacktriangle / \blacktriangledown keys. Here we want 0 minute, so press on \blacktriangle key to remove the star and display 0 then press \checkmark key. Then press \blacktriangledown key to go to next line. Here, we input the temperature setpoint (55°C). Press \checkmark key and using \blacktriangle / \blacktriangledown keys, display 60 (60°C) then press \checkmark key to validate. Display indicates:</p>	<pre> Time 1 0 : * Time 1 0 : 00 Time 1 0 : 00 Value 1 0°C Value 1 55°C </pre>
<p>Press \blacktriangledown key to access next line. Here, we indicate the 2nd program time: Process the same way as before to change time. Here we indicate 6h00. Then press on \blacktriangledown key to access to next line. Here, we input 2nd setpoint value (60°C). Process the same way as before to change S1 temperature setpoint. Display indicates :</p>	<pre> Time 2 * : * Time 2 6 : 00 Value 2 60°C </pre>
<p>Press \blacktriangledown key to access next line. Here, we indicate the 3rd program time: Process the same way as before to change time. Here we indicate 22h00. Then press on \blacktriangledown key to access to next line. Here, we input 3rd setpoint value (55°C). Process the same way as before to change S1 temperature setpoint. Display indicates :</p>	<pre> Time 3 * : * Time 3 22 : 00 Value 3 55°C </pre>

<p>Then press « Esc » key to get back one step and press several times ▼ key to go to line #10: Press ✓ key. In our sample, we want to duplicate values except Saturday and Sunday. So we have to select « Tue. To Fri. ». To do this, press ✓ key. Note: If you want to duplicate all the days of the week, select “Tue. To Sun. » instead. Display indicates: Go to next line Press ✓ key, select « YES » and press ✓ key to validate.</p>	<p>Copy Monday from Tue.to Sun. Tue. To Fri. ✓Tue. To Sun. Copy Monday from Tue.to Fri. Activate copy NO</p>
<p>Now go to Saturday and press ✓ key. Required setpoint is 55°C all the day, so let * : * or input 0h00 for Time 1. Go to line #2. Press ✓ key and using ▲ / ▼ keys, display 55°C, corresponding to required setpoint. Press « Esc » key and select now Sunday line. Repeat same procedure as for Saturday, required setpoint being 55°C all day.</p>	<p>Saturday 60°C Time 1 0h00 / * : * Value 1 0°C Value 1 55°C Sunday 60°C Sunday 55°C</p>
<p>Clock program is now completed and effective. Press « Escape » key several times to go back to S1 menu.</p>	

9.4.2 High and Low S1 temperature alarm

High temperature alarm :

The controller includes a security closing the primary control valve AND stopping primary pump(s) in case of too high S1 measured temperature, compared to the S1 temperature setpoint. 3 parameters define this alarm :

- Delta T (DT) high alarm, 10°C by default above S1 setpoint. This delta T follows the current setpoint. If setpoint is 60°C, high alarm condition will appear if S1>70°C (60+10°C).
- High alarm temporization, 1 minute by default. If delta T is exceeded, the temporization starts. When it ends, if delta T still exceeded, the high temperature alarm will be effective: Primary pump(s) stopped and primary control valve signal at 0% (request for closing). Alarm button will red flash and event stored into memory. Furthermore, relay 1 and 2 will be activated by default as relay 1 is general default and relay 2 is high temperature alarm. Temporization is the same for high and low temperature alarms.
- Acknowledgement type: acknowledgement can be manual or automatic, depending of local rules. Manual restart = need to acknowledge default on site (or via modbus if connected). Automatic restart = if temperature drops down, the unit will start.

Low temperature alarm :

- The same way, an alarm indicates if S1 temperature is too low. Alarm condition = S1 < S1 setpoint – DT after the temporization. This alarm acknowledges automatically (automatic restart by default) and doesn't stop pump and doesn't close the primary control valve.
- Alarm button will red flash and event stored into memory. Furthermore, relay 1 will be activated by default as relay 1 is general default. Temporization is the same for high and low temperature alarms.

Alarms parameters' settings :

<p>1. Go to line #3 of S1 Menu and press ✓ key to access to high alarm Delta T setting. Press ▲ / ▼ keys to change the value. Setting range: 0 to 50°C. ① : The 10°C default value suits almost all cases. Only few installations can motivate a value change.</p> <p>2. Then press ✓ to confirm or « Escape » to cancel value change</p> <p>3. Press ▼ key to go to next line</p>	<pre>S1 MENU 3 / 8 ⇐ ... DT° High alarm Sp. 10°C ...</pre>
<p>4. Low temperature alarm delta T is set the same way. Setting range: 0 to 50°C. ① : The -10°C default value suits almost all cases. Only few installations can motivate a value change.</p> <p>5. Then press ✓ to confirm or « Escape » to cancel value change</p> <p>6. Press ▼ key to go to next line</p>	<pre>S1 MENU 4 / 8 ⇐ ... DT° Low alarm Sp. -10°C ...</pre>
<p>7. High and Low alarm delay before it activates. Press ▲ / ▼ keys to change the value. Setting range: 0 to 60 minutes ① : This delay ensures the actuator has had sufficient time to close (high alarm) or open (low alarm) before alarm occurs. For slow actuators (>60 secs) it is recommended to increase the value higher than running time.</p> <p>8. Then press ✓ to confirm or « Escape » to cancel value change</p> <p>9. Press ▼ key to go to next line</p>	<pre>S1 MENU 5 / 8 ⇐ ... Alarm delay 1.0min ...</pre>
<p>10. This parameter is set to acknowledge high temperature alarm AUTOMATICALLY or MANUALLY. Press ✓ key and use keys ▲ / ▼ to change the value NO<->YES. Validate by pressing ✓ key. ① : Please refer to local rules to check if Automatic restart is allowed.</p> <p>11. Press ▼ key to go to next line</p>	<pre>S1 MENU 6 / 8 ⇐ ... High Al.T° AutoReset NO ...</pre>

9.4.3 S1 Temperature controller

This is the main PID control loop of the unit, connected to S1 temperature sensor and acting on primary control valve and eventually on primary pump speed (variable primary pump(s) option). Default values are suitable for most of installations and might not be changed. Only particular installations may need parameters' change.

<p>1. The right number indicates the actual PID output (%).</p>	<pre>S1 MENU 7 / 8 ⇐ ... S1 T° controller nnn% ▶</pre>
<p>2. Press ✓ key to access to PID settings</p>	<pre>S1 T° controller 1 / 6 ⇐ Proportional band: 40.0°C 40 °C 0°C ↓ 1000°C [--- --- --- --- --- --- --- --- --- ---]</pre>
<p>3. Press ✓ key to change the proportional band (P factor of PID). Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values: 0 to 1000°C.</p>	<pre>S1 T° controller 2 / 6 ⇐ Integral factor : 15s 15 s 0s ↓ 2000s [--- --- --- --- --- --- --- --- --- ---]</pre>
<p>4. Press ▼ key to go to next line.</p>	<pre>S1 T° controller 3 / 6 ⇐ Derivative factor : 2s 2 s 0s ↓ 2000s [--- --- --- --- --- --- --- --- --- ---]</pre>
<p>5. Press ✓ key to change the integral factor (I factor of PID). Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values: 0 to 2000 s.</p>	<pre>S1 T° controller 4-6 / 6 ⇐ Present value: 60°C Setpoint : 60°C Controller output: nnn%</pre>
<p>6. Press ▼ key to go to next line.</p>	<pre>S1 T° controller 4-6 / 6 ⇐ Present value: 60°C Setpoint : 60°C Controller output: nnn%</pre>
<p>7. Press ✓ key to change the derivative factor (D factor of PID). Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values: 0 to 2000s.</p>	<pre>S1 T° controller 4-6 / 6 ⇐ Present value: 60°C Setpoint : 60°C Controller output: nnn%</pre>
<p>8. Press ▼ key to go to next line.</p>	<pre>S1 T° controller 4-6 / 6 ⇐ Present value: 60°C Setpoint : 60°C Controller output: nnn%</pre>
<p>Lines 4 to 6 are read only informations. Line 4 : Measured S1 temperature Line 5 : S1 setpoint temperature Line 6 : S1 PID controller output in %</p>	
<p>Press twice « Esc » key to get back to main menu.</p>	

9.5. Thermal treatment function

Principle :

S1 temperature setpoint is raised (70°C by default) as per a clock program, for a set duration, in general between 1 and 2 hours, depending of secondary flow rate and storage tank capacity.

The function includes an alarm indicating eventually the temperature – tolerance (2°C by default) was never reached during the treatment. Treatment setpoint has also to be reached at least once.


Example: For a 70°C treatment setpoint, if S1 never reaches 68°C, alarm will be activated when function stops.

When function has ended, the normal S1 temperature setpoint is back and high temperature alarm is inhibited as per “Inhibition time” parameter. When inhibition time has passed, the high temperature alarm is active again.



If the green led of ⓘ key is flashing, it is not possible to change the thermal treatment setpoint. To solve this, access to technician level (see further on), go to “Communication” sub-menu and select « Modbus RTU », then press ✓ key. Go to the last line « Writing priority » and select « POL468 » then press ✓ key. The green LED will stop flashing. You can now change the setpoint. When done, do not forget to go back to Communication\Writing priority and to select “BMS”.

Settings :

<p>1. From the main menu and using ▲ / ▼ keys, go to line “Thermal treatment” as shown here: Then press ✓ key to access this sub-menu</p>	<p>STANDARD 1 / t ⇌ ... Thermal treatment OFF ▶</p>
<p>2. Press ✓ key to enable (ON) / disable (OFF) the thermal treatment, using ▲ / ▼ keys and pressing ✓ to confirm. 3. Press ▼ key to go to next line.</p>	<p>Thermal treatment 1 / 6 ⇌ Enable OFF ...</p>
<p>4. Press ✓ key to change setpoint value, using ▲ / ▼ keys and pressing ✓ to confirm. Setting range: 60°C to 80°C. ⓘ : <i>Primary inlet temperature should be at least 7 to 70°C higher than this setpoint to reach thermal treatment temperature. If not the case, thermal treatment failure alarm may appear at the end.</i> 5. Press ▼ key to go to next line.</p>	<p>Thermal treatment 2 / 6 ⇌ Setpoint 70°C 70 °C 60°C ↓ 80°C [--- --- --- --- --- --- --- --- --- ---]</p>
<p>6. Press ✓ key to access to clock program.</p>	<p>Thermal treatment 3 / 6 ⇌ Schedule ▶</p>
<p>7. Use ▲ / ▼ keys to change value and ✓ key to confirm date(s) and time(s).  DATES / TIMES FORMATS « * » symbol means « all ». For a daily treatment at 2h00, you need to input: Date= *. *. *.**** (all the days of the week, all the monthes, all the year.) and Time= 02.00 (2 h 00) For a weekly treatment, every Monday at 2h00(recommanded frequency), you need to input: For a monthly treatment, each 1st of the month at 2h00, without taking care of the day it is, you have to input: Date= *.01. *.**** and Time=02.00 (not the best frequency)</p>	<p>Date *. *. *.**** (dw.dd.mm.yyyy) Time *. * (hh.mm) Date *. *. *.**** Time *. * Date Mo.* *.**** Time 02.00</p>
<p>8. Press « Escape» key to get back to thermal treatment sub-menu 9. Press ▼ key to go to next line. 10. Press ✓ key to change treatment’s duration. Duration is voluntary set to zero, as you have to estimate tank/installation loading time, depending of nominal secondary flow rate, recycling loop flow rate and storage tank volume. Duration setting : 0 to 240 min (4 hours)</p>	<p>Thermal treatment 4 / 6 ⇌ Duration 0min 0 min ↓0min 240min [--- --- --- --- --- --- --- --- --- ---]</p>

<p>Example : Sec. Flow rate $Q=2\text{m}^3/\text{h}$, Tank volume $500\text{L}=V=0,5\text{m}^3$ and recycling flow rate $q=1000\text{ l/h}$. Tank loading time, so minimal treatment duration = $V/(Q-q)$ Let $0,5/(2-1)=0,5$ hour. If you wish to maintain at this temperature for 1 hour, you need 1h30 duration (0.5h+1h) or 90 minutes.</p>	
<p>11. Press ∇ key to access to next line.</p>	
<p>12. Press \checkmark key to change tolerance value. Use \blacktriangle / \blacktriangledown kys to change value and \checkmark key to validate. Setting values : 0 to 10°C. <i>Ⓢ : If setpoint temperature – tolerance is not reached, an error message will appear at the end of treatment duration.</i></p>	<p>Thermal treatment 5/ 6 \rightleftarrows Tolerance 2°C 2 °C 0°C \downarrow 10°C [--- --- --- --- --- --- --- --- --- ---]</p>
<p>13. Press ∇ key to access to next line.</p>	
<p>14. Press \checkmark key to change S1 high temperature alarm inhibition time. Press \blacktriangle / \blacktriangledown keys to change value and \checkmark key to validate. Setting values : 0 to 240 minutes.</p>	<p>Thermal treatment 6/ 6 \rightleftarrows ... Inhibition time 30min</p>
<p>15. Press twice « Esc » key to get back to main menu.</p>	



When Thermal Treatment is on-going, the Alarm/function led button flashes green.

9.6. Safety function

Principle :

This function activates the 4 pumps' relays at the same time without considering pumps faults' inputs.

Valve and pump(s)' signals are settable, at the opposite of end-user access level.

If the unit is equipped with P1/P2 variable speed pump(s) on the primary side, it is also possible to adjust their 0-10V signal, Y2=100% by default.

This function forces also the actuator signal Y1=50% by default.

Settings:

<p>1. From the main menu and using \blacktriangle / \blacktriangledown keys, go to line "Safety function" as shown here: Then press \checkmark key to access this sub-menu</p>	<p>STANDARD 1/ t \rightleftarrows ... Safety function OFF \blacktriangleright</p>
<p>2. To activate the function, press \checkmark key</p>	<p>Safety function 1/3 \rightleftarrows Enable OFF</p>
<p>3. Select « ON » using \blacktriangledown key then press \checkmark key</p>	<p>\checkmarkOFF ON</p>
<p>4. Display indicates « Enable ON » and the alarm/function button red flashes, showing a function is on-going: <i>Ⓢ : It is possible at any time to check the on-going function(s) (or alarm(s)) by pressing \triangle button, please refer to "Alarm/function button part."</i></p>	<p>Safety function 1/3 \rightleftarrows Enable ON Pump signal setpoint 100% Valve signal setpoint 50%</p>
<p>5. Press ∇ key to access to next line.</p>	
<p>6. Press \checkmark key to change P1/P2 signal value (Y2 signal). Use \blacktriangle / \blacktriangledown keys to change its value and press \checkmark key to validate or "Esc" key to cancel change. Setting values: 0 to 100%. <i>Ⓢ : If not 0-10V primary pump(s), no effect.</i></p>	<p>Safety function 2/3 \rightleftarrows Pump signal setpoint 100% 100 % 0°C 100%\downarrow [--- --- --- --- --- --- --- --- --- ---]</p>
<p>7. Press ∇ key to access to next line.</p>	
<p>8. Press \checkmark key to change primary valve signal value (Y1 signal). Use \blacktriangle / \blacktriangledown keys to change its value and press \checkmark key to validate or "Esc" key to cancel change. Setting values: 0 to 100%.</p>	<p>Safety function 3/3 \rightleftarrows Valve signal setpoint 50% 50 % 0°C \downarrow 100% [--- --- --- --- --- --- --- --- --- ---]</p>
<p>9. To stop the function, go to line#1 and press twice \checkmark key (state OFF on display). The alarm button then stops flashing, except if other alarm(s) or/and function(s) are pending.</p>	
<p>10. Press « Esc » key to get back to main menu. Press again "Esc" to point 1st line of Main menu.</p>	



When the safety function is ON, the Alarm(s)/Function(s) button green flashes.

9.7. ECO function.

Eco function principle:

When control valve is sufficiently closed (valve signal ≤ "Y1 setpoint") during a sufficient long time ("switch-on delay"), primary pump(s) switch(es) off and primary mixing valve closes down.

The system is switched ON when S1 temperature has gone down more than the S1 setpoint value – "Hysteresis" parameter. It is normal that the primary control valve starts to open during the function. This to anticipate valve opening when the pump will start again.

Secondary pump is still in operation during the Eco function.

NOTE : ECO function needs at least one primary pump. If not the case (2 port control valve systems for example, the function disappears from the menu.

Settings:

1. From the main menu and using ▲ / ▼ keys, go to line "ECO/Booster" as shown here: Then press ✓ key to access this sub-menu	STANDARD 1 / t ↔ ... ECO/Booster OFF ▶
2. To activate ECO function, press ▼ key to access line #2 and then press ✓ key	ECO/Booster 2 / t ↔ Enable OFF
3. Select « ON » using ▼ key then press ✓ key	✓OFF ON
4. Display indicates « Enable ON » Press ▼ key to access to next line.	ECO/Booster 2 / t ↔ Enable ON
5. Press ✓ key to change the switch-on delay. Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values : 0 to 20 minutes. Ⓢ : <i>Delay to be adjusted as per installation characteristics.</i>	ECO/Booster 3 / t ↔ Switch-on delay 5min 5 min
6. Press ▼ key to access to next line.	0min ↓ 20min [--- --- --- --- --- --- --- --- --- ---]
7. Press ✓ key to change the hysteresis value on S1. Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values : 0 to 20 °C. Ⓢ : <i>To avoid repetitive and frequent pump start/stop, select a value above 5°C.</i>	ECO/Booster 4 / t ↔ Hysteresis 5°C 5 °C
8. Press ▼ key to access to next line.	0°C ↓ 20°C [--- --- --- --- --- --- --- --- --- ---]
9. Press ✓ key to change the Y1 setpoint value (max allowed signal on the valve to allow the function to start). Use ▲ / ▼ keys to change its value and press ✓ key to validate or "Esc" key to cancel change. Setting values : 0 to 80%. Ⓢ : <i>Do not input too high value. The pump would be stopped under medium-high load!</i>	ECO/Booster 5 / t ↔ ... Y1 setpoint 10% 10 %
10. Press ▼ key to access to next line.	0% ↓ 80% [--- --- --- --- --- --- --- --- --- ---]
11. To stop the function at any time, go to line #1, press twice ✓ key (state OFF on display). The alarm button then stops flashing if function was running, except if other alarm(s) or/and function(s) are pending.	
12. Press « Esc » key to get back to main menu. Press again "Esc" to point 1 st line of Main menu.	



When ECO function is running, display indicates « ECO function RUNNING », the main menu indicates "ECO/Booster RUNNING" and the Alarm(s)/Function(s) key green flashes.

9.8. Pump(s) menu



This menu appears if at least one pump is declared. Otherwise it is not visible.

Settings :

1. From the main menu and using ▲ / ▼ keys, go to line "Pump(s) Menu" as shown here: *Note that declared pump(s) is(are) displayed on the right side. Then press ✓ key to access this sub-menu	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">STANDARD</td><td style="text-align: right;">1 / t ↔</td></tr> <tr><td>...</td><td></td></tr> <tr><td style="text-align: right;">Pump(s) menu</td><td style="text-align: right;">P1 P3 ▶</td></tr> <tr><td>...</td><td></td></tr> </table>	STANDARD	1 / t ↔	...		Pump(s) menu	P1 P3 ▶	...			
STANDARD	1 / t ↔										
...											
Pump(s) menu	P1 P3 ▶										
...											
2. Full menu pump represented here: * If P1/P2 not 0-10V controlled, no effect on the unit.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Pump(s) Menu</td><td style="text-align: right;">1 / 4 ↔</td></tr> <tr><td>- P1P2-</td><td></td></tr> <tr><td>Minimum speed*</td><td style="text-align: right;">25%</td></tr> <tr><td>Maximum speed*</td><td style="text-align: right;">100%</td></tr> <tr><td>-P3P4-</td><td></td></tr> </table>	Pump(s) Menu	1 / 4 ↔	- P1P2-		Minimum speed*	25%	Maximum speed*	100%	-P3P4-	
Pump(s) Menu	1 / 4 ↔										
- P1P2-											
Minimum speed*	25%										
Maximum speed*	100%										
-P3P4-											
3. Press ▼ key to access to next line.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Pump(s) menu</td><td style="text-align: right;">2/nn ↔</td></tr> <tr><td>Minimum speed</td><td style="text-align: right;">25%</td></tr> <tr><td>...</td><td></td></tr> </table>	Pump(s) menu	2/nn ↔	Minimum speed	25%	...					
Pump(s) menu	2/nn ↔										
Minimum speed	25%										
...											
4. N/A for constant speed pump. If optional variable speed pump(s) installed, please refer to specific manual. Press ▼ key to access to next line.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Pump(s) menu</td><td style="text-align: right;">3/nn ↔</td></tr> <tr><td>Maximum speed</td><td style="text-align: right;">100%</td></tr> <tr><td>...</td><td></td></tr> </table>	Pump(s) menu	3/nn ↔	Maximum speed	100%	...					
Pump(s) menu	3/nn ↔										
Maximum speed	100%										
...											
5. N/A for constant speed pump. If optional variable speed pump(s) installed, please refer to specific manual. Press « Esc » key to get back to main menu. Press again "Esc" to point 1 st line of Main menu.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Pump(s) menu</td><td style="text-align: right;">1 / t ↔</td></tr> <tr><td>...</td><td></td></tr> <tr><td style="text-align: right;">Pump(s) menu</td><td style="text-align: right;">P1 P3 ▶</td></tr> <tr><td>...</td><td></td></tr> </table>	Pump(s) menu	1 / t ↔	...		Pump(s) menu	P1 P3 ▶	...			
Pump(s) menu	1 / t ↔										
...											
Pump(s) menu	P1 P3 ▶										
...											

9.9. Test sequence



This function is used at the factory and is part of manufacturing process of the unit to check control valve, pump(s), relays are operating. However, we recommend using the « Wired inputs-outputs » sub-menu for a deeper inputs/outputs tests, especially for commissioning or maintenance operations.


Settings :

1. From main menu, use ▲ / ▼ keys to go to « Test sequence » line : Then Press ✓ key	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">STANDARD</td><td style="text-align: right;">1 / t ↔</td></tr> <tr><td>...</td><td></td></tr> <tr><td style="text-align: right;">Test sequence</td><td style="text-align: right;">▶</td></tr> </table>	STANDARD	1 / t ↔	...		Test sequence	▶				
STANDARD	1 / t ↔										
...											
Test sequence	▶										
2. To activate the sequence, press ✓ key then ▼ key to select ON and press ✓ key. Then controller activates outputs (contacts and signals) in the following order : All signals to 0V →Relay R1→Command P1→Command P2→Command P3→Command P4→230V 3pts -→230V 3pts +→Relay R2→Relay R3→Y1 to 10V→Y2 to 10V→End of sequence and back to normal control.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">1 / 4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>✓OFF</td><td></td></tr> <tr><td>ON</td><td></td></tr> </table>	Test Sequence	1 / 4 ↔	Enable	OFF	✓OFF		ON			
Test Sequence	1 / 4 ↔										
Enable	OFF										
✓OFF											
ON											
3. Press ▼ key to go to next line.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">2/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	2/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	2/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
4. Press ✓ key to change pumps' test duration. Use ▲ / ▼ keys to change value and press ✓ key to validate or "Esc" key to cancel change. Setting range: 0 to 60 secondes (4 sec by default).	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">3/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	3/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	3/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
5. Press ▼ key to go to next line.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">4/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	4/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	4/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
6. Press ✓ key to change 0-10V signals' duration. Use ▲ / ▼ keys to change value and press ✓ key to validate or "Esc" key to cancel change. Setting range: 0 to 60 secondes (4 sec by default).	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">4/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	4/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	4/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
7. Press ▼ key to go to next line.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">4/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	4/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	4/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
8. Press ✓ key to change contacts' tests duration. Use ▲ / ▼ keys to change value and press ✓ key to validate or "Esc" key to cancel change. Setting range: 0 to 60 secondes (4 sec by default).	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">4/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	4/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	4/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										
9. Press « Esc » key to get back to main menu. Press again "Esc" to point 1 st line of Main menu.	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td style="text-align: right;">Test Sequence</td><td style="text-align: right;">4/4 ↔</td></tr> <tr><td>Enable</td><td style="text-align: right;">OFF</td></tr> <tr><td>Pump test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Signal test time</td><td style="text-align: right;">4s</td></tr> <tr><td>Relay test time</td><td style="text-align: right;">4s</td></tr> </table>	Test Sequence	4/4 ↔	Enable	OFF	Pump test time	4s	Signal test time	4s	Relay test time	4s
Test Sequence	4/4 ↔										
Enable	OFF										
Pump test time	4s										
Signal test time	4s										
Relay test time	4s										

9.10. Modbus RTU Communication Menu



Be sure modbus cable wires are connected on T1 terminal (upper left corner of the control box) to get Modbus communication.




Wiring made on terminals labelled A+ and B-. If cable length exceeds 3 meters, it is recommended to use a shielded cable, connecting shield to REF terminal.

Settings :

<p>1. From main menu, use \uparrow / \downarrow keys to go to « Communication » line: Then Press \checkmark key</p>	<p>STANDARD / t \leftrightarrow ... Communication \rightarrow</p>
<p>2. Press \downarrow key, then \checkmark key to check/modify communication parameter(s). If a least one parameter is modified, you have to RESTART the controller. For that, go to line#1 and press \checkmark key, then select ON by pressing \downarrow key and finally press \checkmark key.</p>	<p>Communication 1 / 2 \leftrightarrow Restart OFF Modbus RTU (RS485) COMM.OK</p>
<p>3. Press \checkmark key to access to communication parameters. Use \uparrow / \downarrow keys to select line and press \checkmark to access line. 4. Use \uparrow / \downarrow keys to change value and press \checkmark to validate or “Esc” key to cancel. Explanations below : Controller address from de 0 to 32 (10 by default) Communication speed from 600 to 115200 baud (defaut=19200) Parity : Even/Odd/None (by default) Bit stop number : 1 (by default) / 2 For any change, RESTART controller (same as previous screen) See below :</p>	<p>Modbus RTU (RS485) 1 / 6 \leftrightarrow Slave Address 10 Baud rate 19200 Parity None Stop 1 bit Restart required ! OFF Writing priority POL468</p>
<p>5. Writing priority: POL486 (by default) / BMS If priority let to controller (POL468), it is not possible to write value from BMS, but only possibility to read values. If it is necessary to write values from BMS to controller, select « BMS ». In this case, it is not possible to modify some values from controller. Concerned parameters are listed bellow :</p> <ul style="list-style-type: none"> • S1 temperature setpoint • Acknowledge default • Thermal treatment setpoint 	<p>Writing priority POL468 POL 468 BMS</p>
<p>6. If no restart required, press twice « Esc » key to get back to the main menu.</p>	

Connecting several control boxes (units):

Controller address being changeable, it is then possible to connect up to 32 units. In the case of several units connected each other, respect Modbus cable wirings as per bellow diagram:



Modbus parameters' list :

COMMUNICATION POINTS

	Speed / Vitesse :	19200	
MODBUS PARAMETERS / PARAMETRES	Bit number / Nbre de bits :	8	* In case of multiple controllers, change ModBus slave number * En cas d'échangeur en cascade changer le N° d' esclave du mode bus
	Stop bit / Bit de stop :	1	
	Parity / Parité :	None / Aucune	
MODBUS :	Mode :	RTU	** On some BMS, add/subtract one ** sur certains superviseurs, ajouter/soustraire 1
	Adresse* :	10	

ModBus Points (English)	Points ModBus (Français)	Modbus Punkte (Deutsch)	MODBUS adress** Adresse ModBus**	Type	Sub-type Sous-type	Mode	Value Valeur	Comment Commentaire
----------------------------	-----------------------------	----------------------------	-------------------------------------	------	-----------------------	------	-----------------	------------------------

Read Only digital / Lecture seule Digitaux								
Cmd_P1	Cmd_P1	Pumpe1_Befehl	14	HR_16	BOOL	R	0=Off, 1=On	Command(e) P1
Cmd_P2	Cmd_P2	Pumpe2_Befehl	15	HR_16	BOOL	R	0=Off, 1=On	Command(e) P2
Cmd_P3	Cmd_P3	Pumpe3_Befehl	16	HR_16	BOOL	R	0=Off, 1=On	Command(e) P3
PriP1_Alarm_On	PriP1_Alarme_Ma	Pumpe1_Alarmmeld	18	HR_16	BOOL	R	0=OK, 1=Alarm	P1 Fault / Défaut P1
PriP2_Alarm_On	PriP2_Alarme_Ma	Pumpe2_Alarmmeld	19	HR_16	BOOL	R	0=OK, 1=Alarm	P2 Fault / Défaut P2
SecP3_Alarm_On	SecP3_Alarme_Ma	Pumpe3_Alarmmeld	22	HR_16	BOOL	R	0=OK, 1=Alarm	P3 Fault / Défaut P3
High_T_Alarm	Alarme_T_Hte	Max_Alarm	26	HR_16	BOOL	R	0=OK, 1=Alarm	S1 High Temp Alarm/Alarme haute S1
General_Default	Alarme_Synthese	Sammelstoerung	27	HR_16	BOOL	R	0=OK, 1=Alarm	General default / Défaut synthèse
ThermTr_Alarm	Alarme_TrTh	ThBe_ALARM	31	HR_16	BOOL	R	0=OK, 1=Alarm	Therm.Treat. Failed / Echec traitement therm.
Th_Tr_running	TrTh_activ	Leg_activ	35	HR_16	BOOL	R	0=Off, 1=On	Therm.Treat. On going / Trait. Therm. En cours
Remote_Control	Contrl_Distant	Fernsteuerung	36	HR_16	BOOL	R	0=Off, 1=On	Remote control / Contrôle distant
BOOSTER	BOOSTER	BoostMode	40	HR_16	BOOL	R	0=Off, 1=On	BOOSTER active
ECO	ECO	EcoMode	41	HR_16	BOOL	R	0=Off, 1=On	ECO activated
PD_Pumps_Fault	PD_Default_pompes	PD_Pumpenfehler	42	HR_16	BOOL	R	0=Off, 1=On	Synthesis pump(s) fault / Défaut synthèse pompe(s)
SAFETY_FCT	FCT_SECOURS	Sicherheit_Fkt	75	HR_16	BOOL	R	0=Off, 1=On	Safety function / Fonction Secours
(16 bit integer/Entier 16 bit)*								

Read Only Analogic / Lecture seule Analogiques								
Soft Version	Verion soft	Soft Version	33	HR_16	int16	R		Software version / Version logiciel
P1P2 Nbr of pump	Nbre pompe P1P2	P1P2 Nbr of pump	71	HR_16	int16	R	0/1/2/3	0=No pump / 1=P1 / 2=P2 / 3=P1+P2
P3P4 Nbr of pump	Nbre pompe P3P4	P3P4 Nbr of pump	72	HR_16	int16	R	0/1/2/3	0=No pump / 1=P3 / 2=P4 / 3=P3+P4
Signal P1P2	Signal P1P2	Drehz_P1P2	44	HR_16	int16	R	%	Primary pump signal Y2 / Signal pompe primaire Y2
Signal Valve	Signal Vanne	Signal_Ventil	46	HR_16	int16	R	%	Control valve 1 signal Y1/ Signal servomoteur 1, Y1
S1	S1	S1	49	HR_16	int16	R	°C	Sensor 1 measurement / Mesure Sonde S1
S2	S2	S2	50	HR_16	int16	R	°C	Sensor 2 measurement / Mesure Sonde S2
S3	S3	S3	51	HR_16	int16	R	°C	Sensor 3 measurement / Mesure Sonde S3
Relay1 Fct	Fct Relais 1	Relais1 Fkt	62	HR_16	int16	R	0/1/2/3/4/5/6/7/8/9/10	Relay1 function / Fonction relais 1
Relay2 Fct	Fct Relais 2	Relais2 Fkt	63	HR_16	int16	R	0/1/2/3/4/5/6/7/8/9/10	Relay2 function / Fonction relais 2
Relay3 Fct	Fct Relais 3	Relais3 Fkt	64	HR_16	int16	R	0/1/2/3/4/5/6/7/8/9/10	Relay2 function / Fonction relais 3
Mode	Mode	Mode	66	HR_16	int16	R	0=Standard, 1=PREMIUM	
(16 bit integer/Entier 16 bit)*								

Read-Write digital / Lecture-Ecriture Digitaux								
Alarm(s) acknowledge	Acquit.alarne(s)		200	HR_16	BOOL	R/W	1=Reset fault. Pulse point necessary 30 seconds On/Off	
(16 bit integer/Entier 16 bit)*								

Read-Write Analogic / Lecture-Ecriture Analogiques								
SP_T_Sec_Outlet	Consigne_S1	SW_T_Sek_Ausgang	210	HR_16	int16	R/W	°C	S1 fixed setpoint (DHW) / Consigne fixe S1 (ECS)
ThTr_setpoint	PC_TrTh	ThBe_Sollwert	212	HR_16	int16	R/W	°C	Thermal treatment setpoint / Consigne trait. thermique
(16 bit integer/Entier 16 bit)*								


9.11. Wired Inputs / Outputs menu



This sub-menu is very useful to commission or to diagnostic an unit : check valve is opening/closing, check pump is running or check contacts' relays. It is more powerful than the « Test sequence » sub-menu.

Settings :

<p>1. From the main menu, use ▲ / ▼ keys to go to the line « Wired inputs – outputs » : Then press ✓ key.</p>	<p>STANDARD 1 / t ⇌ ... Wired inputs-outputs ▶</p>
<p>2. Press ▼ / ▲ keys to access to selected line and press ✓ to validate. AI=Analog inputs=temperature sensor(s) AO=Analog outputs=Y1, Y2 0-10V signal(s) DI=Digital inputs=Pump(s) fault + Remote contact DO=Digital outputs=Command pump(s) + Relays contacts + 230V 3pts contacts</p>	<p>Wired inputs – outputs 1 / 4 ⇌ Analog Inputs ▶ Analog Outputs ▶ Digital Inputs ▶ Digital Outputs ▶</p>
<p>Analog inputs Inputs (like outputs) are gathered on the controller by blocks labelled T1 to T12. On these blocks, each terminal is labelled. Example: S1 sensor is connected to terminals B1 of T2 block All inputs are read only, no possibility to change a sensor value.</p>	<p>Analog Inputs 12/12 ⇌ ----- T2 CONNECTOR ----- B1 :S1 : 60°C B2 to B4 :--- : 0°C ----- T3 CONNECTOR ----- B5 to X4 :--- : 0°C</p>
<p>Analog outputs Navigate into the display using ▲ / ▼ keys and press ✓ key to change value. Signal Y1 = Primary Valve control signal, 0 to 10 volts. Signal Y2 = Primary pump signal P1/P2, 0 to 10 volts (used with variable speed pump(s) only) « AUT » value indicates the controller controls this signal nnn% indicates the actual signal value (0%=0V up to 100%=10V). PASS INTO MANUAL MODE It is possible to override the original signal. To do that, select the line and press ✓ key. Now, using ▲ / ▼ keys, change from « AUT » to «MAN» value, meaning “MANUAL”. Now press ✓ key and using ▲ / ▼ keys, input the signal value you want. Example: To check the actuator is moving and the primary valve fully closes, enter 0%. At the opposite, to check it fully opens, input 100%. To reput a point into automatic mode, select MAN and by pressing ▲ or ▼, display “AUT” and validate by pressing ✓ key, then press « Esc ».</p> <p> Once at least 1 point is in manual mode, ⓘ button is orange lit. DO NOT FORGET TO PUT THE POINT(S) IN AUTO BEFORE LEAVING THIS SUB-MENU. To see easily which point(s) are in manual mode, a « ⌘ » logo is displayed on the corresponding line :</p>	<p>Analog Outputs 1/5 ⇌ ----- T4 CONNECTOR ----- X5 :Y1 SIGNAL : AUT-nnn% X6 :Y2 SIGNAL : AUT-nnn% X7 : --- : AUT- 0% X8 : --- : AUT- 0% AUT → MAN → nnn% To find back a point let in manual mode corresponding to our example, you can see the “⌘» symbol :</p> <p>Wired inputs – outputs 1 / 4 ⇌ Analog Inputs ▶ Analog Outputs ⌘ ▶ Digital Inputs ▶ Digital Outputs ▶</p>
<p>Binary (or digital) inputs All inputs are read only, no possibility to change a sensor value. External stop = remote contact. If ON, Remote is active and the unit is in standby mode.</p>	<p>BI-IO Aut.st 1/6 ⇌ ----- T5 CONNECTOR ----- D1 : P1 Alarm : NORMAL D2 : --- : NORMAL D3 : P3 Alarm : NORMAL D4 : --- : NORMAL D5 : External stop : OFF</p>

<p>Binary (or digital) outputs</p> <p>As for analog outputs, it is possible to force these contacts to ON or OFF. To do that, pass from AUTO to MANual mode. R1=Relay 1, R2=Relay 2, R3=Relay 3. Com. FER.Y1 = Closing contact for 230V 3 points actuator (-) Com. OUV.Y1 = Opening contact for 230V 3 points actuator (+)</p> <p>Example: We want to Start P2 pump (considering it is present). Select line #5, press ✓ key, press ▼ key then ✓ key and press ▼ then ✓ key to pass from OFF to ON. Do not forget to repass in automatic mode after the test.</p> <div style="text-align: center;">  </div> <p>Once at least 1 point is in manual mode, ⓐ button is orange lit. DO NOT FORGET TO PUT THE POINT(S) IN AUTO BEFORE LEAVING THIS SUB-MENU. To see easily which point(s) are in manual mode, a « 𐀀 » logo is displayed on the corresponding line →</p> <p>Press « Esc » key to get back to main menu. Press again "Esc" to point 1st line of Main menu.</p>	<pre> BO-IO Aut.st 1/12 ↔ ----- T10 CONNECTOR ----- Q1: R1 COMMAND : AUT-OFF ----- T11 CONNECTOR ----- Q2: P1 COMMAND : AUT-ON Q3: --- : AUT-OFF Q4: P3 COMMAND : AUT-ON ----- T12 CONNECTOR ----- Q5: --- : AUT-OFF Q6: Y1 CloseCommd : AUT-ON Q7: Y1 OpenCommd : AUT-OFF Q8: R2 COMMAND : AUT-OFF Q9: R3 COMMAND : AUT-OFF Wired inputs – outputs 1 /4 ↔ Analog Inputs ▶ Analog Outputs ▶ Digital Inputs ▶ Digital Outputs 𐀀 ▶ </pre>
---	---

10. Configuration access level

This access level is identical to technician level EXCEPT it displays an extra « Configuration » sub-menu. The configuration sub-menu allows to configure sensor(s)' number and also pump(s)' number. It is a part of the factory manufacturing process, as each unit must have its sensor(s)/pump(s) configured.

10.1. Login

Access code is 2000.

1. From the main menu, go to line#2 : **Password enter ▶**. Then press ✓ key
OR
Press a few seconds on ✓ key
2. Display indicates « Login » and a cursor is placed on **0 - - -**
3. Using ▲ / ▼ keys (meaning + / -), enter the 1st digit and validate by pressing ✓ key. The 1st digit must be 1. So you have to display **2 - - -** by pressing once the + key, then pressing ✓ key.
4. Now comes the 2nd digit that must be 0 (zero). Just press on ✓ key as the default digit value is already zero.
5. Repeat the same operation for 3rd and 4th digits that must be zero also. For that, just press twice the ✓ key.
6. Once correct code is entered, information display appears (hardware/software versions, controller reference...). Press « Esc » key to come back to the main menu.
The display now shows 2 keys on its top right corner, indicating configuration sub-menu is now accessible.

Remark: After 10 minutes without pressing any key, the software logs out, the keys disappear and the software is back to end-user access level.

10.2. Logout

You don't have to wait 10 minutes until logging out. It is possible to log out at any time.



For that :



1. Press a few seconds on ✓ key
2. Select « Log off » by pressing ▼ key
3. Press ✓ key
4. The key symbol has disappeared from the display. Access level is now back to end-user.

10.3. Configuration menu

Note ! If Reseted contrôler or spare part controller, pump(s) and sensor(s) number **MUST** be configured using this sub-menu.

Settings :

1. From the main menu, use ▲ / ▼ keys to go to the line « Configuration » : Then press ✓ key.	STANDARD / t ⇌ ⇌ Configuration ▶
2. Press ✓ key to change daylight saving time parameters. By default it set on automatic mode	Configuration 1/ 19 ⇌ ⇌ Daylight sav.time
3. Here is the description of possible settings : Use ▲ / ▼ keys to change line or value, ✓ key to validate or “Esc” to cancel. Enable/Disable auto time change. Keep on yes. Here is the time to add/substract, should be kept to 1 hour Month for summer time (should be kept to March) Day for summer time (should be kept to Sunday) Do not change Time change will occur at 2h00 at night Month for winter time (should be kept to October) Day for winter time (should be kept to Sunday) Do not change Time change will occur at 3h00 at night UTC reference time (European UTC by default)	Daylight sav.time 1/11 ⇌ ⇌ Enable Yes Time 1h Start month Mar Start week day Su Start offset 4 Start hour 2h End month Oct End week day Su End offset 4 End hour 3 UTC difference -60min
4. Press Esc to get back to the configuration sub-menu.	
5. Press twice ▼ key then ✓ key to select STANDARD. If PREMIUM is indicated, put on STANDARD mode using ▲ / ▼ keys and ✓ key to validate.	Configuration 3/ 19 ⇌ ⇌ Model selection STANDARD
6. Press ▼ key to access to next line.	
7. Press ✓ key to change actuator’s type. Use ▲ / ▼ keys to change value and ✓ key to confirm or “Esc” key to cancel. For AquaFirst, AquaGenius or AquaCompact, select Aq.F ① : <i>Other values correspond to other products.</i>	Configuration 4/ 19 ⇌ ⇌ Actuator type Aq.F ✓Aq.F
8. Press ▼ key to access to next line	...
9. Keep on OFF state. Press ▼ key to access to next line	Configuration 5/ 19 ⇌ ⇌ Cooling Mode OFF
10. Press ✓ key to enable/disable S2 temperature sensor. Press ▲ / ▼ keys to change value to YES/NO and press ✓ key to validate or “Esc” key to cancel. ① : <i>S2 activation enable extra line on main display and in sub-menus.</i>	Configuration 6/ 19 ⇌ ⇌ ... S2 Activation NO ...
11. Press ▼ key to access to next line	
12. Press ✓ key to enable/disable S3 temperature sensor. Press ▲ / ▼ keys to change value to YES/NO and press ✓ key to validate or “Esc” key to cancel. ① : <i>S3 activation enable extra lines on main display and sub-menus.</i>	Configuration 7/ 19 ⇌ ⇌ ... S3 Activation NO ...
13. Press ▼ key to access to next line	
14. Press ✓ key to define primary pump(s) number. Use ▲ / ▼ keys to change value to P1 for 3 Port control valve option or to NONE for other configurations and press ✓ key to confirm.  THIS STEP IS MANDATORY TO GET AN OPERATING UNIT !	Configuration 8/ 19 ⇌ ⇌ P1P2 pump selector NONE / P1* ... * Actual configuration appears on the right side of the line
15. Press ▼ key to access to next line	
16. Press ✓ key to define primary pump(s) number. Use ▲ / ▼ keys to change value to P3 and press ✓ key to confirm.  THIS STEP IS MANDATORY TO GET AN OPERATING UNIT !	Configuration 9/ 19 ⇌ ⇌ P3P4 pump selector P3* ... * Actual configuration appears on the right side of the line
17. Press ▼ key to access to next line	
18. Press ✓ key to change relay 1 function. Use ▲ / ▼ keys to change value and ✓ key to validate.	Configuration 10/ 19 ⇌ ⇌ ... Relay 1 function General alarm

<p>Default value is General alarm: will be activated for any default Possible values are :</p> <p style="text-align: right;">No action Any default (default value) High temperature alarm on S1 Low temperature alarm on S1 ECO function running Clock program Thermal treatment running Secondary tank loaded (requires S2 sensor) Pump(s) default Fouling function on alarm (requires S3 sensor) (N/A)</p> <p>19. Press ∇ key to access to next line</p>	<p>...</p> <p>Nothing ✓General alarm High T° alarm Low T° alarm ECO function Timer** Th.Tr activated Tank loaded Pump default HE fouled Primary too low</p>
<p>20. Press \checkmark key to change relay 2 function. Use \wedge / ∇ keys to change value and \checkmark key to validate. Default value is High T° alarm. Possible values are the same as Relay 1. See above.</p> <p>21. Press ∇ key to access to next line</p>	<p>Configuration 11/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>Relay 1 function General alarm ✓High T° alarm</p> <p>...</p>
<p>22. Press \checkmark key to change relay 3 function. Use \wedge / ∇ keys to change value and \checkmark key to validate. Default value is nothing (no action). Possible values are the same as Relay 1. See above.</p> <p>23. Press ∇ key to access to next line</p>	<p>Configuration 12/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>Relay 3 function General alarm ✓Nothing</p> <p>...</p>
<p>24. Press \checkmark key to enable 230V 3 points output. Use \wedge / ∇ to change value OFF/ON, press \checkmark to enable or « Esc » to cancel. ① : 230V 3 points output is disabled as not used on standard units and to avoid noise and to avoid wear of the corresponding relays.</p> <p>25. Press ∇ key to access to next line</p>	<p>Configuration 13/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>3 points valve on Y1 OFF</p> <p>...</p>
<p>26. Press \checkmark key to modify 3 points valve opening time. Use \wedge / ∇ keys to change value and press \checkmark key to validate or “Esc” key to cancel. ① : No action if 3 points valve is set to OFF.</p> <p>27. Press ∇ key to access to next line</p>	<p>Configuration 14/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>- Open time 30s</p> <p>...</p>
<p>28. Press \checkmark key to modify 3 points valve closing time. Use \wedge / ∇ keys to change value and press \checkmark key to validate or “Esc” key to cancel. ① : No action if 3 points valve is set to OFF.</p> <p>29. Press ∇ key to access to next line</p>	<p>Configuration 15/ 20 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>- Close time 30s</p> <p>...</p>
<p>30. Press \checkmark key to change the display language. Use \wedge / ∇ keys to change value and press \checkmark key to validate or “Esc” key to cancel. ① : All menus will be displayed in the selected language***</p> <p>31. Press ∇ key to access to next line</p>	<p>Configuration 16/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>Language selection English</p> <p>...</p>
<p>32. Press \checkmark key to production reset the controller. Use \wedge / ∇ keys to change value NO/YES and press \checkmark key to validate or “Esc” key to cancel.</p> <p> At the opposite of describe restart found in some sub-menus, this production reset put all parameters by default, as described into this manual, putting the controller in its original state, before factory configuration of pump(s and sensor(s). It will be necessary to reconfigure these last ones.</p> <p>33. Press ∇ key to access to next line</p>	<p>Configuration 17/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>Production reset NO</p> <p>...</p>
<p>34. Software version. Read only. Also visible into the info menu or by pressing the ① key.</p> <p>35. Press ∇ key to access to next line</p>	<p>Configuration 18/ 19 \leftrightarrow \leftrightarrow</p> <p>Software version V.nn</p> <p>...</p>
<p>36. Press \checkmark key then use \wedge / ∇ to change value OFF/ON, press \checkmark to enable or « Esc » to cancel.</p> <p> ANY CHANGE INTO THIS MENU, EXCEPT LANGUAGE SELECTION REQUIRES A CONTROLLER RESTART!</p> <p>37. Press « Esc » key to get back to main menu. Press again “Esc” to point 1st line of Main menu.</p>	<p>Configuration 19/ 19 \leftrightarrow \leftrightarrow</p> <p>...</p> <p>Restart required ! OFF</p> <p>...</p>

** If Timer selected, and extra line will be displayed. This will add a clock program, with 6 possible daily time schedules to ON/OFF relay contact. Please refer to S1 clock program as settings are similar (except they apply to ON/OFF instead of a setpoint value).





*** It is not necessary to restart the controller when changing the language only.

11. Alarms/Functions and acknowledgement




11.1. Alarms

Alarms are indicated via  key that red flashes.





To acknowledge an alarm, press twice on  key, press  key, then on  key (Execute) and finally on  key to confirm. If several alarms are displayed but not active anymore, they will all be cleared and their status passes from FAULT to NORMAL.

Possible alarms are listed below :

Display :	Meaning :
Alarm history nn/tt	Nn=Alarm(s) number, tt=Total lines number
Acknowledge	Press  , then  and  to acknowledge ALL alarms
S1 150°C ▶	S1 sensor is faulty or wires disconnected: value = 150°C
P1 Alarm FAULT ▶	Primary pump 1 default.
P3 Alarm FAULT ▶	Pump 3 default (secondary charge pump).
S1 high T° FAULT ▶	High temperature alarm measured by S1 temperature sensor.
S1 low T° FAULT ▶	Low temperature alarm measured by S1 temperature sensor.
Therm. Treatm. FAILURE ▶	Thermal treatment failed



To get alarm detail (date and time it occurred), select requested alarm into the list and press  key.

11.2 Functions

Running functions are indicated with  button led green flashing. The different functions are listed below. Pressing  button indicates the last function event, with its occurrence details (date and time).

Display :	Meaning :
Alarm list detail nn / tt	Nn=Function(s) number, tt=Total lines number
SAFETY ACTIVE ▶	Safety function running
SAFETY INACTIVE ▶	End of safety function
Thermal Treatment Started ▶	Thermal treatment running
Thermal Treatment Stopped ▶	End of Thermal treatment
ECO MODE STARTED ▶	ECO function running
ECO MODE STOPPED ▶	End of ECO function
STANDBY ACTIVE ▶	Remote function running
STANDBY INACTIVE ▶	Fin de la fonction Remote

11.3 Events'list

If  button is not flashing, press it once. If flashing, press it 3 times to access to events' list. The last 50 events are displayed from more recent to oldest. To get more info, select one and press  key to get occurrence date and time.

12. Production RESET

If lot of parameters have been changed (PID, functions...) and you want to find back all default settings at once, you should proceed the production reset.

Access code is 2000.

1. From the main menu, go to line#2: Password enter **▶**. Then press ✓ key
OR
Press a few seconds on ✓ key
2. Display indicates « Login » and a cursor is placed on **0 - - -**
3. Using ▲ / ▼ keys (meaning + / -), enter the 1st digit and validate by pressing ✓ key. The 1st digit must be 2. So you have to display **2 - - -** by pressing once the + key, then pressing ✓ key.
4. Now comes the 2nd digit that must be 0 (zero). Just press on ✓ key as the default digit value is already zero.
5. Repeat the same operation for 3rd and 4th digits that must be zero also. For that, just press twice the ✓ key.
6. Once correct code is entered, information display appears (hardware/software versions, controller reference...). Press « Esc » key to come back to the main menu.
The display now shows two keys on its top right corner, indicating the factory level access is activated. Now, most of the lines show « ▶ » at their end, meaning their access is now possible and the configuration menu can be accessed now.
7. Go to "Configuration" line and press ✓ key.
8. Go to "Production Reset" line and press ✓ key.
9. Press ▼ key to select **YES** and press ✓ key to confirm
10. Controller restarts
11. Repeat steps 1 to 7 to access again to Configuration sub-menu
12. Adjust parameters: AT LEAST pumps' number: P1/P2 and P3/P4
13. Then go to the last line "Restart required!", press ✓ key, then ▼ and ✓ key to restart.
14. Controller restarts with new configuration.

Remark: After 10 minutes without pressing any key, the software logs out from factory level, the key disappears and the software is back to end-user access level.

Log out

You don't have to wait 10 minutes until logging out. It is possible to log out at any time.

For that :

1. Press a few seconds on ✓ key
2. Select « Log off » by pressing ▼ key
3. Press ✓ key
4. The key symbol has disappeared from the display. Access level is now back to end-user.
5. Save parameter at line No. 3

13. Trouble shooting

FINDINGS	PROBABLE CAUSES	REMEDIES
Controller doesn't start	No power from mains or PCB transformer	Check FU5 (230V transfo), FU7 (24VDC transfo) and mains supply
Pump(s) not operating	Locked rotor or damaged	Force to rotate. Replace if required
	Corresponding led is not lit on power board	Check FU5 (transfo primary) and FU6 (transfo secondary) fuses
	Pump relay damaged	Replace Power Board
	Pump protection fuse blown	Check then replace if necessary
	High Alarm condition detected	Clear alarm then reset system
	No voltage to control board terminals	Check power supply cable and fuses
	No voltage to pump motor terminals	Check protection fuse on main board, cable condition and connections
	Controller improperly set	Check pumps' configuration into Configuration menu
Low temperature alarm	Primary pump stopped	See "Pump(s) not operating"
	Too low primary temperature	Check for a closed valve in the primary
	Too high tap water flow rate (SI)	Reduce buffer vessel charging flow rate
	Set point too high	Adjust setpoint into S1 Menu
	Control valve remains closed	See "Modulating valve does not operate"
Modulating valve does not operate	Damaged or broken actuator	Test and replace if necessary
	Broken or improperly tightened coupling	Check and replace if necessary
	Valve blocked	Replace
	No signal from the controller	Check 24V AC fuse on power board
	Supply wires improperly tightened	Check wires, re-tighten connections
	Actuator stroke restricted	Dismount then clean the valve
High temperature alarm	Charging pump stopped (SI versions)	Refer to "Pump not operating" above
	Low recirculation flow rate (I versions)	Check and fix problem
	Alarm differential too low	Check and set the controller
	Modulating valve not closing	Refer to previous box above
	Too much differential pressure across the modulating valve	Check the way the TWM is piped-up. Mixing arrangement should be used
Correct temperatures across the exchanger not obtained. Valve and pumps operating satisfactorily	Excessive exchanger scaling at the primary or secondary side	Open and clean the exchanger according to cleaning instructions
	Primary pipe work obstructed or strainer upstream clogged	Inspect primary pipe work. Clean strainer on the primary side
	Isolation valve closed	Open isolation valves
	Air presence in the primary	Purge. Check no high parts where air could be trapped exist
	Excessive pressure drops	Check pipe size is suitable for nominal flow rate
Temperature does not increase in the buffer vessel and the tap water value is correct.	Recirculation flow rate exceeds charging flow rate.	Check and measure charging and recirculation flow rates. Adjust when necessary
		Recirculation FR < 0.6 x Charging FR

14. Maintenance and repairs

Cetetherm AquaCompact does not require any specific maintenance.

The frequency of the inspections depends on the water hardness, temperature and flow rate.

Weekly inspections:

- Check for leaks on pipes and components.
- Check that the operation control system is stable, and that the temperature does not fluctuate. Temperature hunting causes unnecessary wear of valves, actuators.

Annually:

- Check the control box electrical connections tightening.
- Check the control valve for leaks.
- Check the electric current requirement of the circulation pump.
- Clean and disinfect the system at least once a year, see [12](#)
-
-
- [Antibacterial treatment of the Aquatank.](#)

Regularly:

- The cleaning schedule for the exchanger will depend on the quality of the water and how much demand is placed on the system.
- Flush-out the tank on a regular basis.
- Check regularly that the safety devices (like safety valve, etc.) are working properly.
- Lime scaling on the connected devices.

Scaling of the secondary side will be evidenced by:

- A high pressure drop on the secondary side of the exchanger that should not exceed 50 kPa on all models (heat exchanger only).
- Improper temperature range on the secondary side of the exchanger.
- Low temperature difference between inlet and outlet on the primary side of the exchanger when the control valve is fully open.



Only replace any defective parts with the **original** spare parts.
Please contact your Cetetherm distributor for spare parts, note serial number and model designation.



Maintenance work must be carried out by a qualified and authorized technician.



Hazard of severe electrical shock or burn.
Before cleaning and servicing, disconnect power supplies.



Risk of burns. Let the pipes cool down before starting out with maintenance work.

14.1 Antibacterial treatment of the Aquatank

Clean and disinfect the system at least once a year



Whenever the Aquatank or exchanger circuits are to be drained, it is crucial to let the water cool down to preclude any risk of scalding or burns.

The Aquatank is fitted with a dismantling inspection hole.

To work on the inside of the tank:

- use the shut-off to isolate the exchanger kit
- isolate the installation's power circuit
- close the cold water inlet, and drain out the tank.

Access is through the inspection hole, once the tightening screws have been loosened.

NOTE: Comply with all currently applicable governing standards of, cleaning and disinfecting the system at least once a year.

14.2 Clean the heat exchanger plates (P series)



DO NOT USE hydrochloric acid or any acid that could corrode stainless steel plates.

DO NOT USE water with more than 330 ppm Cl when making a cleaning solution. Nitric (for calcium carbonate), sulfamic (for calcium sulphate) or citric (for silt) acids can be used. Concentration should not exceed 4% at 60°C.



Protective gloves and glasses should always be worn while these operations.

Carefully rinse the plates with clean water after cleaning.

1. Measure the tightening lengths of the exchanger (distance between two frames plates).
2. Open the exchanger by loosening and removing the support anchor bolts.
3. Remove the plates without damaging the gaskets and readjusting their orientation and position.
4. Clean the plates gently to avoid damage them. Do not use metal implements – use a metal-free nylon brush.
5. Lime scale can be removed by soaking the plates in a correctly-dosed acid solution
6. Refit the plates in the same order and position, as when they were disassembled.
7. Tighten up the exchanger, using the tightening length as initially.
8. Make sure the thermometer pocket of the control sensor is properly cleaned.

Ask your local Cetetherm Company for more information on maintenance procedures, disassembly, cleaning, remounting; see the Cetetherm instructions manual, document reference number 1644725-01.

14.3 Clean the fusion-bonded or copper brazes plate heat exchangers (F/B-series)



Only the specially designed, pre-fitted cleaning kit and compatible agents should be used for cleaning fusion-bonded or soldered plate heat exchangers.



Protective gloves and glasses should always be worn while these operations.

Use the specially-engineered plugs and isolate the secondary circuit using the gate valves.



Unclip the heat insulator at the top and bottom of the exchanger

Isolate the exchanger and use the special connective fittings for cleaning, removing the plugs. CIP connector: 3/4"



Cetetherm recommends the use of a pre-fitted Cetetherm CIP 20-type cleaning unit together with a specific cleaning agent, such as AlfaPhos that is environmentally friendly. There are several product solutions available depending on the cleaning job to be tackled. Use a neutralizing solution, such as AlfaNeutra, before rinsing.



Alfa CIP 20



- The circulator systems and pumps require no specific maintenance action.
- The motor-driven control valves do not need any particular maintenance. Run annual checks to ensure that the valve glands do not show signs of leakage.
- The control box requires no specific maintenance action. Run an annual check to make sure the electrical connections hold tight.

14.4 Open the control box

Remove the front panel by turning the lock button counter clockwise and lift up the cover.




14.5 Fuses replacement

The control box is fitted with a set of fuses to protect the different components against overload. Extra fuses are included in the control box for quick servicing.



The service work must be carried out by an authorized service technician.
Turn off the power supply before starting to work.



Picture 1

Fuse	FU1	FU2	FU3	FU4	FU5	FU6	FU7
Protection	P 1	P 2 N/A	P 3	P 4 N/A	230V Transfo. primary (Power PCB protection)	24V AC actuator	24V DC Controller
Size	5 x 20	5 x 20	5 x 20	5 x 20	5 x 20	5 x 20	5 x 20
Rating	2,5 A	2,5 A	2,5 A	2,5 A	200 mA	1 A	500 mA
Voltage	250 V	250 V	250 V	250 V	250 V	250 V	250 V

14.6 Pumps' number

The pumps' configuration and connections is factory made.
In a servicing situation the correct pump must be identified.

Codification	Meaning	Connected pump(s)
No kit	1 charging pump	P3
2PE kit	1 charging pump	P3
3PE kit	1 primary pump + 1 charging pump	P1+P3

14.7 Relay 1, 2 and 3 wiring

Relay 1 output can be (Normaly Open) or NC (Normaly Closed) using corresponding terminals.
Relays 2 and 3 are NO (Normaly Open).

- Relay 1 wiring

Operating mode	Connections on PCB bottom terminal ADE_430
NO	C-NO (36-35)
NC	C-NC (36-37)

- Relay 2 wiring: Terminals 38 (C) and 39 (NO) on PCB ADE_430.
- Relay 3 wiring: Terminals 40 (C) and 41 (NO) on PCB ADE_430.



Please refer to Electric wiring diagram chapter for connections. If 230V AC through relay, do not exceed 2A by relay.

14.8 Remote control contact


The unit can be placed in “standby” mode, via the remote contact. To do so, a volt free contact should be connected directly on the controller in the upper part of the control box. The contact is wired on terminals D5 and M of T5 block.




Please refer to Electric wiring diagram chapter for connections. **DO NOT** power supply this contact, Volt free contact only.

Working principle :

When contact is open (by default), unit is operating normally.

If contact closes, pump(s) is (are) stopped and control valve closes (0V signal). The unit is then in standby mode, but still power supplied as the controller. The  key flashes and pressing on it you can read « STANDBY ACTIVE ».



15 Assembly of the charging kit to the Aquatank

NOTE: The photos are non-binding – changes are liable to be made without notice.

1. Start by fitting the insulation onto the tank.



The insulation must be mounted before the tank is definitively connected up. Refer to the guidelines of the Aquatank instructions manual.



2. Exchanger kit
Shown here, the 3P kit, primary circuit three-way valve, controller and circulation system.



3. Install the hot water outlet fitting on the top vertical tank connection.



4. Mount the cold water inlet fixture onto the bottom vertical tank off-take. If necessary, use the sleeve provided to install the fixture if the tank tubing is configured as male.



5. Once the bottom fixture has been fitted, install the shut-off valve and the hose connector.



6. Screw the support coil into the one-ended tank sleeve. On 300-L models, use the lower-left sleeve.




7. Then place the locking ring on the support coil.



8. Set an initial position by fitting the threaded rod of the support into the tube and screwing the union connector at the exchange outlet into the pre-fitted tank shut-off valve.



9. Readjust the assembly to make sure the exchange is perfectly vertical and parallel to the tank shell. Once this is done, tighten the support ring blocking screws.



10. Then sit the pump / balancing valve / safety valve assembly opposite the secondary circuit exchanger inlet (bottom-left connection). Do not forget the flat gasket. **The two parts are assembled using a union connector installed on the pump side.** Electrically connect the pump to the control box or header cabinet, depending on the equipment.



11. Mount the exchanger heat-insulator by assembling the shells and fixing them together with the plastic clips at the top and bottom of the exchanger.

The charging kit should look like the one in the photo.

The final step is to install the connector hose hydraulically linking the bottom of the tank to the pump suction system.

Cetetherm AquaCompact
Installation, service and operating instructions



12. Connect the upper flexible pipe to the pump.



13. Repeat the procedure to link the bottom of the hose to the cold water inlet fixture located toward the base of the tank.

The charging kit is now mounted on the storage tank.
At that point, it may or may not be equipped with a pre-mounted primary kit like the one shown in the photo opposite.



Now establish electrical and hydraulic connections to the exchanger's primary circuit. Follow the instructions given in chapter [16 Flowchart](#).

15.1 Specific points for assembling the M3 charging kit

The kit is anchored onto a support sleeve via a clamp collar that should be positioned to the middle of the sleeve before being adjusted and tightened. Use the adjustable support fixture on the exchanger when guiding the kit into the correct position.

Sit the exchanger and its clamp collar on the support sleeve and tighten the locking screws when everything is properly aligned.
Place the "jaws" at the extreme end of the support pipe.



Connecting the top-section hose:

Go through the same procedures as for the bottom-section hose.





Final assembling

NOTE: For the 300L Tank, use the top-section support.




15.2 Mounting the flexible hose onto the tank




16 Flowcharts

16.1 Flowchart AquaCompact




ID.	Description	ID.	Description
A	Primary supply	VR	Balancing valve
B	Primary return	PC	Charging pump (secondary)
HE	Heat Exchanger	PR	DHWC pump (recirculation pump)
V	Shut-off valves	NR	Non Return Valve
PRV	Safety valve	DHW	Domestic Hot water
DC	Drain valve	CW	Cold Water

16.2 Flowchart AquaCompact with primary kit 2PSA




ID.	Description	ID.	Description
S	Immersion temperature sensor	V2p	2-port control valve with self-acting actuator

16.3 Flowchart AquaCompact with primary kit 2PE



ID.	Description	ID.	Description
S	Immersion temperature sensor	CB	Control box
V2p	2-port control valve with actuator	S3	Temperature sensor
S2	CIP sensor		

16.4 Flowchart AquaCompact with primary kit 3PE



ID.	Name	ID.	Name
S	Immersion temperature sensor	V(cv)	Closing valve (primary side valves)
S2	CIP sensor	V3p	3-port control valve with actuator
CB	Control box	PP	Primary pump
S3	Temperature sensor	MB	Mixing bottle


17 Wiring the charging pump

Note: The charging pump has not been wired before delivery. The five wires cable connected to the control box must be wired to the charging pump.


Please proceed as follow:

Ensure the system is not connected to the main power supply. If the control box is connected to the main power supply, ensure that the main switch is turned off and locked.

With Grundfos UP20-45N :



With Wilo Star Z 20/7:



With Grundfos UPS32-80N:



18 Special instructions for options

18.1 Special instructions for 2PSA primary kits

Please refer to the guide supplied with the thermostatic control valve.

Always position the black slot upwards, see [2.1 2PSA primary kit – Thermostatic 2-way control valve](#) featuring.

18.2 Special instructions for 2PE primary kit


The actuator has been factory-calibrated. No special setting is needed.

Electrical wiring



Wire terminal

Wiring diagram



19 Commissioning report

All parts are not applicable to the AquaCompact.

COMMISSIONING REPORT			
Installation			
Tightening dimension control			
Air vent position			
Settling Pot presence on primary			
Boiler Brand, installation and power			
Mixing bottle required / Presence			
Balancing valve presence on Indirect (Semi Instantaneous) installations			
Close drain valves			
Primary conformity:			
Secondary conformity:			
Accessibility of unit and components			
Configuration menu			
Sensors			
Pumps			
Other			
Primary Pumps:		Secondary Pumps:	
Pump 1	<input type="checkbox"/>	Pump 2	<input type="checkbox"/>
		Pump 3	<input type="checkbox"/>
		Pump 4	<input type="checkbox"/>
Electrical bridges control for pumps on power plate			
Pump 1	<input type="checkbox"/>	Pump 2	<input type="checkbox"/>
		Pump 3	<input type="checkbox"/>
		Pump 4	<input type="checkbox"/>
Control valve working	<input type="checkbox"/>		
Settings			
DHW secondary outlet T° setting: S1			
PID setting			
High alarm setting	<input type="checkbox"/>	Manual	<input type="checkbox"/>
Thermal Treatment	<input type="checkbox"/>	Type	Setting
Eco function activation	<input type="checkbox"/>		
Booster function activation	<input type="checkbox"/>		
Other functions activated	<input type="checkbox"/>		
Relay 1 function	<input type="checkbox"/>		
Relay 2 function	<input type="checkbox"/>		
Trending and/or Modbus value activated	<input type="checkbox"/>		
Volt free Remote contact wired or not	<input type="checkbox"/>		
TRIAC 230 V connections wired or not	<input type="checkbox"/>		
Other comments:			
Identification of the unit:			
Unit ID N°	Installer / Company Name	Installation site	Date
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

20 Declaration of Conformity

PED 2014/68/EU art. 4.3, LVD, EMC, RoHS
Declaration of Conformity
Déclaration de Conformité
Konformitätserklärung
Conformiteitsverklaring

Manufacturer / Fabricant / Hersteller / Fabrikant:

Cetetherm SAS

Route du Stade ZI du Moulin, 69490 Pontcharra sur Turdine, France

- Heat exchanger unit, District heating system for heating and/or Domestic Hot Water
- Echangeur thermique, Système de chauffage urbain pour le chauffage et l'eau chaude sanitaire
- Fernwärme-Kompaktstationen für Heizung und/oder Trinkwarmwasser
- Warmtewisselaarunit, stadsverwarmingsysteem voor verwarmingswater en/of sanitair warm water

Products / Produits / Produkte / Producten	Models / Modèles / Varianten / Modellen
AQUACOMPACT	All / Tous

- Above mentioned products are in article 4.3 according to PED 2014/68/EU
- Les produits susmentionnés figurent à l'article 4.3 conformément à la DESP 2014/68/EU
- Vorstehend benannte Produkte fallen unter Artikel 4.3 der DGRL 2014/68/EU
- Bovengenoemde producten zijn conform artikel 4.3 van Richtlijn Drukapparatuur 2014/68/EU

Used directives / Directives utilisées / Angewendete Direktiv / Gebruikte richtlijnen :

- PED 2014/68/EU
- LVD 2014/35/EU
- EMC 2013/35/EU
- RoHS 2011/65/EU

Used other standards and specifications / Autres normes et spécifications utilisées / Weitere angewendete Standards / Andere gebruikte standaarden en specificaties :

- EN 60335-1 partly / EN 60335-1 en partie / EN60335-1 teilweise / EN6335-1 gedeeltelijk
- EN 60204-1 partly / EN 60204-1 en partie / EN 60204-1 teilweise / EN60204-1 gedeeltelijk

Jean-Michel Montoni

Pontcharra sur Turdine, Mai 2024

Jean-Michel Montoni

Product manager / Chef de produit / Bevollmächtigter / Conformiteits verantwoordelijke

21 Warranty

Our equipment comes with a 24-month warranty from the date of shipment.

The manufacturer's liability is limited to the replacement of any defective part that cannot be repaired. No other financial compensation may be claimed in any case under the warranty.

The nature and probable cause of the defect must be reported to the manufacturer before any action is taken. The defective part should then be returned to our factory in France for assessment unless written agreement to proceed otherwise has been obtained from Cetetherm. The results of the assessment can only state whether the terms of the warranty apply.

Exclusion factors:

Non-compliance with the guidelines for installation, configuration and maintenance:
Over pressures, water-hammer, scaling, noncompliant water quality

Also excluded from the warranty:

- Fitting costs, refitting costs, packaging, transport, and any accessories or equipment not manufactured by Cetetherm, which will only be covered by any warranties issued by said third-party manufacturers.
- Any damage caused by connection errors, insufficient protection, misapplication or faulty or careless operations.
- Equipment disassembled or repaired by any other party than Cetetherm.

Non-payment will lead to all operational warranties covering the delivered equipment being terminated.

How to contact Cetetherm

Our contact details are updated on our website www.cetetherm.com.

Cetetherm sas
ZI du Moulin, Route du Stade
69490 Pontcharra sur Turdine - France
www.cetetherm.com

Cetetherm

The logo for Cetetherm features the company name in a bold, black, sans-serif font. A thick, green horizontal bar is positioned directly beneath the text, extending slightly beyond the left and right edges of the letters.